

Инструкция по установке шатра Pavillion

Перед поездкой.

- Внимательно прочитайте всю инструкцию. Детально ознакомьтесь с особенностями данной модели, условиями и ограничениями использования.
- Убедитесь, что все комплектующие в наличии. Тщательно проверьте качество узлов изделия, особенно после долгого хранения или перед первым использованием.

Перед установкой.

- Определите место установки. Оно должно быть ровным и очищенным от камней, веток и других твердых и острых предметов.

ВНИМАНИЕ: ДЛЯ УСТАНОВКИ ТРЕБУЕТСЯ МИНИМУМ ДВОЕ ЛЮДЕЙ.

- Держитесь подальше от воздушных линий электропередач.
- Не устанавливайте шатер под деревьями, во избежание падения на тент веток деревьев в ненастную погоду.
- Для предотвращения повреждения шатра и получения травм, хорошо закрепите все колышки и оттяжки.
- При ветре устанавливайте шатер углом к направлению ветра.
- Ни при каких обстоятельствах шатер не должен использоваться для укрытия автомобиля, лодки и других предметов.

Оптимальное применение.

Местоположение: Защищенная низина/ Долина.

Погодные условия: Обычные/ Умеренные.




Ветроустойчивость: Средняя.

Назначение: Временное укрытие.

Помните, что (УФ) ультрафиолетовые лучи могут повредить вашу палатку, если вы подвергнете ее воздействию прямых солнечных лучей в течение длительных периодов времени.

Комплектация

1	Тент шатра	1 шт.	F
2	Центральная дуга с соединителем	1 шт.	A
3	Центральная 1/2 дуга	2 шт.	D
4	Дуга боковая с соединителем	4 шт.	B
5	Установочная стропа	1 шт.	E
6	Опора	4 шт.	C
7	Колышек	12 шт.	
8	Оттяжка	8 шт.	
9	Чехол	1 шт.	



ИНСТРУКЦИЯ ПО УХОДУ ТКАНЬ 100% ПОЛИЭСТЕР

КАРКАС 100% СТАЛЬ

Сделано в Китае

Установка шатра

ВАЖНО: Все четыре опоры должны быть расположены квадратом на расстоянии 450 см. Для правильной установки, используйте установочную стропу для разметки **Е**.

- Соберите центральную дугу с пластиковым крестообразным соединителем **А** (рис. 2.1) и две 1/2 центральных дуг **Д** (рис. 2.1).
- Присоедините каждую 1/2 центральных дуг к целой центральной дуге через крестообразный соединитель (получится крест из дуг рис. 2.2).

- Соберите четыре боковые дуги с Т-образными соединителями **В**.

ПРИМЕЧАНИЕ: На каждой дуге не собирайте последние концевые звенья в это время (рис. 2.3).

- Соедините боковые дуги с крестом из дуг (рис. 2.4). Должна получиться купольная крестовая конструкция.

ПРИМЕЧАНИЕ: Убедитесь, что металлические штифты зашелкнулись в ответном пазу. Возможно, придется повернуть каждую дугу по часовой или против часовой стрелки.

- Разложите тент шатра **Ф** и накиньте его на верх каркаса (рис. 3.2)
- Частично закрепите тент к дугам (рис. 3.3) с помощью Велко (липучек). Они находятся на внутренней стороне тента.
- Установите пластиковые опоры **С** по четырем углам. Правильная геометрия размечается с помощью Разметочной стропы **Е**.

ПРИМЕЧАНИЕ: Опоры должны наклоняться к центру шатра, а вертикальные пазы обращены наружу.

- Соберите последние звенья на концах боковых дуг **В**.
 - Вставьте в опору **С** концы боковых дуг **В** и проверните их до фиксации штифта в пазах опоры (рис. 3.4).
 - Повторите это с остальными опорами и дугами.
 - Закрепите разметочную стропу **Е** крючками в отверстиях опор **С**, которые обращены к центру шатра.
 - Колышками через отверстия в опорах, закрепите опору к земле одну за одной, натягивая установочную стропу.
- Отсутствие провисания стропы обеспечивает правильную геометрию установки шатра (рис. 3.5).

- Закрепите крючки тента **Ф** в квадратных пазах/отверстиях опор **С** (рис. 3.6).
- Затягивая стропы тента, создайте необходимое натяжение ткани (рис. 3.7).
- Защелкните пряжки в углах вокруг дуг и затяните (рис. 3.8 и 3.9)
- Окончательно закрепите тент к дугам свободными креплениями (рис. 4.1)
- Используя оттяжки и колышки, дополнительно зафиксируйте шатер.
- Снимите и уберите установочную стропу для последующего использования (рис 4.2)

Ваш шатер готов к использованию.









Разборка

Разборка шатра производится в обратной последовательности. Перед упаковкой тента, убедитесь в том, что он высох.

Хранение


1. Каркас и все колышки должны быть размещены в чехлах для хранения, чтобы предотвратить повреждение ткани, находящейся в общем чехле.
2. Убедитесь, что все компоненты чистые и сухие перед упаковкой в чехол.
3. Хранить в чистом, сухом месте.

Эта палатка соответствует требованиям по воспламеняемости CPAI-84. Ткань может гореть, если оставить в постоянном контакте с любым источником пламени. Нанесение любого постороннего вещества на ткань палатки может привести к снижению свойств огнестойкости.




Производитель рекомендует дополнительные опции к шатру:


1. Ветрозащитная стенка для защиты от ветра и посторонних глаз.




2. Ветрозащитная стенка с окнами и молнией.



3. Соединитель шатров для организации большого лагеря.



4. Антимоскитная сетка



Pavillion Shelter Pitching Instructions

Before the trip.

- Please study the instruction carefully. Please study in detail the shelter specifications and conditions and use limitations of this model.
- Make sure all the shelter components are in place. Please check carefully on the shelter components, especially after long-term storage or before the first use.

Before putting up the shelter.

- Select the site for the shelter set-up. The ground should be flat and clear from rocks, tree limbs, and other hard or sharp objects

NOTE: THIS TENT SHOULD BE ERECTED BY AT LEAST TWO PERSONS.

- Stay away from overhead power lines.
- Do not place the shelter under trees to avoid tree branches falling on the tent in inclement weather.
- To avoid personal injury and damage to the shelter, secure all the pegs and guy ropes.
- In windy conditions set up the shelter with its corner into the wind.
- Under no circumstances should this tent be used to shelter a car, boat, or other items.

Best Suitable For:

Location: Secure Lowland/Valley.

Weather Conditions: Normal/Mild.





Wind Resistance: Medium.

Function: Temporary Shelter.

Be aware that (UV) ultraviolet rays will damage your tent if you expose it to direct sunlight for longer periods of time

Component List

1	Shelter Flysheet	1 pc.	F
2	Center pole with the hub	1 pc.	A
3	Center ½ pole	2 pcs.	D
4	Side pole with connector	4 pcs.	B
5	Mark-out sling	1 pc.	E
6	Leg Foot	4 pcs.	C
7	Peg	12 pcs.	
8	Guy Rope	8 pcs.	
9	Carry bag	1 pc.	



MAINTENANCE INSTRUCTION FABRIC **100%** POLYESTER



FRAME **100%** STEEL

Made in China

Shelter setup

IMPORTANT: All four leg feet should be placed in a square with 450 cm sides. To ensure the correct setup, use the mark-out sling to fix the layout **E**.

- Assemble the center pole with the plastic cross hub **A** (Figure 2.1) and two ½ center poles **D** (Figure 2.1).
- Attach each ½ center pole to the center pole cross hub (you'll get a cross-shaped pole construction, Figure 2.2).
- Assemble the four side poles with T-shaped connectors **B**.

NOTE: On each pole, do not assemble the last end links at this time (Figure 2.3).

- Connect the side poles to the poles cross (Figure 2.4). You should get a domed cross structure.

NOTE: Make sure the metal pins snap into the joggle joint. You may need to turn each pole clockwise or counterclockwise.

- Spread out the shelter flysheet **F** and drape it over the top of the frame (Figure 3.2)
- Partially fasten the shelter flysheet to the poles (Figure 3.3) using velcro straps. They are located on the inside of the shelter flysheet.

- Place the plastic leg feet **C** at the four corners. The correct geometry should be marked out using the Mark-out sling **E**.

NOTE: The leg feet should be inclined toward the center of the shelter, with the vertical notches facing outward.

- Assemble the last end links of the side poles **B**.
- Insert the end of **C** one side pole **B** into a leg foot and turn it until the pin is locked in the notch of the leg foot (Figure 3.4).
- Repeat this operation with the rest of the poles and leg feet.
- Fix the mark-out sling **E** with hooks in the attachment holes of the leg feet **C** facing the center of the shelter.
- By nailing the pegs through the holes in the leg feet, secure the leg feet to the ground one by one, pulling the mark-out sling taut. A properly tightened sling, having no sags, ensures the correct geometry of the shelter setup (Figure 3.5).
- Secure the shelter flysheet hooks **F** in the square slots/holes of the leg feet **C** (figure 3.6).
- Tighten the shelter flysheet slings to ensure the necessary fabric tension (Figure 3.7).
- Snap the buckles in the corners around the poles and tighten the webbing (Figures 3.8 and 3.9)
- Finalize the attachment of the shelter flysheet to the poles by fastening the rest of the velcro straps (Figure 4.1)
- Secure the shelter using the guy ropes and pegs.
- Remove and store the mark-out sling for future use (Figure 4.2)

Your shelter is ready to use.











Take down instructions

To take down the shelter, follow the pitching instructions in the reverse order. Before packing the shelter, make sure it is dry.

Storage


1. The pole set and all the pegs should be placed in their storage cases to prevent damage to the fabric packed in the same bag.
2. Make sure that all the components are clean and dry before packing in the bag.
3. Store in a clean, dry place.

This product meets CPAI-84 specifications. The fabric will burn if left in continuous contact with any flame source. The application of any foreign substance to the product fabric may render the flame-resistant properties ineffective.




The manufacturer recommends additional options for this shelter:


1. Windproof wall for protection from wind and prying eyes.



2. Windproof wall with windows and zipper.



3. Shelter extension connector for setting up a large camp.



4. Anti mosquito net

